

# Chaise Canopy Instructions

Step 1: Unpack all components, making sure that all parts are located.


Parts List:	D. Canopy Fabric
A. Side Frame (2)	E. Adjustment Knob (2)
B. Bottom Support	F. Disc Spring (4)
C. Canopy Frame	G. Bolt (4)

Step 2: Attach the Bottom Support (B) to the two Side Frames (A) using the four Bolts (G) provided. (Note: The Bolts (G) will either be located in the hardware kit or threaded into the ends of the Bottom Support (B).)



Step 3: Unfold Canopy Fabric (D), and fit it over the Canopy Frame (C). Each corner of the Canopy Fabric (D) will have a pocket for the Canopy Frame (C) to slide into, along with Velcro tabs to secure it around the frame.

Step 4: Place two Disc Springs (F) onto the threaded portion of each Adjustment Knob (E). Aligning the tab on the Side Frames (A) with the end of the Canopy Frame (C) tube, thread the Adjustment Knob (E) through the tab and into the Canopy Frame (C). Hand-tighten until the Canopy Frame (C) holds in any position you wish to set it at. CAUTION: Do NOT overtighten the adjustment knob. This may damage the Canopy Frame's internal threads.



Step 5: Move the Chaise Canopy assembly to its desired location and enjoy!