

Party Bar Assembly Instructions

Parts List


- A. Left Leg Assembly – 1
- B. Right Leg Assembly – 1
- C. Front Apron Assembly – 1
- D. Mid-Shelf Assembly – 1
- E. Party Bar Top – 1
- F. Fabric Liner – Top – 1
- G. 1" Square Plastic Plugs - 2
- H. Allen Wrench – 1
- I. Screws – 12
- J. 18" Tile – 6
- K. 12" Tile – 4
- M. Bumpers - 16




Note 1: This assembly requires at least two adults.

Note 2: Verify that all parts are included with the party bar. If you are missing any parts, please contact Customer Service at 205-715-4322.


Step 1: Locate the Party Bar Top (E). Place it upside down onto a soft surface (i.e. its own carton). Please leave the corner protectors on the top to prevent it from getting scratched.




Step 2: Locate the Left and Right Leg Assemblies (A & B). Place the Left Leg Assembly (A) over the Party Bar Top (E), aligning the leg tabs with the tapped screw holes in the top. **MAKE SURE THAT THE APRON HOLES ARE TOWARD THE FRONT OF THE PARTY BAR TOP, FACING TOWARD THE CENTER OF THE TOP.** Attach the leg assembly using (2) screws (I). Hand-start all screws to avoid cross threading. Continue tightening the screws with the supplied Allen Wrench (H). (DO NOT TIGHTEN COMPLETELY). Repeat this process with the Right Leg Assembly (B). (See picture below for identifying holes.)



Step 3: Locate the Mid Shelf Assembly (D). Turn it upside down and have one person hold it with the mid shelf tabs aligned with the mid shelf screw holes in the legs (see above for location). Attach the Mid Shelf Assembly (D) to the Leg Assemblies (A & B) using (4) screws (I). Hand-start all screws to avoid cross threading. Continue tightening the screws with the supplied Allen Wrench (H) (DO NOT TIGHTEN COMPLETELY).



Step 4: Align the outside brackets of the Front Apron Assembly (C) with the tapped holes in Leg Assemblies (A & B). Keep drain holes facing up. Attach the three (3) assemblies using (4) screws (L). Hand-start all screws to avoid cross threading. Continue tightening the screws with the supplied Allen Wrench (H).



Step 5: **SECURELY TIGHTEN** all Party Bar screws with the Allen Wrench.

Step 6: **CAUTION: ASSEMBLED PARTY BAR IS VERY HEAVY.** Lift the Party Bar and carefully turn right side up. Please be careful not to scratch the legs while you are doing this. Level the Party Bar as desired by adjusting the self-leveling glides located in the bottom legs of the Leg Assemblies (A&B).

Step 7: Place Bar Top Fabric Liner (F) onto Party Bar Top (E) along with 18" Tiles (J).

Step 8: Place 4 tile Bumpers (M) on the Mid-Shelf Assembly (D) at the corners of each tile along with 12" Tiles (K).

We, at Meadowcraft, sincerely hope you enjoy your new Party Bar and thank you for your purchase.

Customer Service

205-715-4322

Meadowcraft, Inc.

P.O. Box 1357

Birmingham, Alabama 35201 U.S.A.

"We Put Pride in the Box"