

Party Bar Canopy Instructions

After assembling the party bar, the following instructions show you how to assemble and install the canopy.

1. Locate the front upright extensions (D). While holding it aligned with the holes under the front corners of the party bar top, insert (2) of the 1 ½” bolts (F), tightening securely with a ½” wrench.
2. Locate the rear upright extensions (E). While holding each aligned with the holes under the rear corners of the party bar top, insert (2) of the 1 ½” bolts (F), tightening securely with a ½” wrench.
3. Locate the center section (C) of the canopy frame. Place it on a soft surface (i.e. grass, carpet, its carton, etc.). Take the right side (A) of the canopy frame, and insert the swaged end of the center section (C) into the tube ends of the right side (A). Repeat this operation with the left side (B) of the canopy frame. Make sure that the tabs on each of the canopy frame ends are facing toward the ground when finished.
4. Locate the canopy fabric (G). Fit the canopy fabric onto the canopy frame by sliding each of the frame corners into the triangular pockets on the underside of the fabric. Secure all velcro tabs around the nearest canopy frame brace.
5. With the aid of another person and a small step ladder, lift the canopy over the party bar, inserting the canopy frame tabs into the upright extension tubes. **Please be sure that the overhang of the canopy is to the front of the party bar.**
6. Insert nylon 1” bolts (H) through the punched holes of the upright extensions. Secure the bolts with the nylon nuts (I). Hand tight is all that is necessary.

Thank you for purchasing the Party Bar Canopy with your Meadowcraft Party Bar.